

## NOTES:

- 1. LOADING: TOP CHORD: (REFER TO THE MAIN TRUSS DESIGN FOR TOP CHORD LOADING). BOTTOM CHORD: LL = 0 PSF, DL = 10 PSF.
- 2. REFER TO THE MAIN TRUSS DESIGN FOR LUMBER AND PLATING REQUIREMENTS.
- 3. MAXIMUM BOTTOM CHORD PITCH = 6/12.
- 4. THE END DISTANCE, EDGE DISTANCE, AND SPACING OF NAILS SHALL BE SUCH AS TO AVOID SPLITTING OF THE WOOD.
- 5. FALSE BOTTOM CHORD ONLY DESIGNED TO CARRY VERTICAL LOAD. NO LATERAL (SHEAR) LOAD ALLOWED.
- 6. FILLER MAY EXTEND FOR FULL LENGTH OF TRUSS.