HANGER AND CONNECTOR SCHEDULE

- 1. All WOOD FRAMING CONNECTORS shall be MiTek "USP STRUCTURAL, CONNECTORS", SIMPSON "STRONG-TIE" or equivalent and shall be in accordance with the following schedule unless specifically noted otherwise.
- 2. Refer to MiTek "USP STRUCTURAL CONNECTORS" OR SIMPSON product catalogs for proper installation.
- 3. HARDWARE not referenced in the following schedule shall be installed to framing with fasteners per manufacturer's recommendations for maximum capacity.
- 4. NAILS FOR CONNECTORS should be installed in all round holes. If MAX is noted on the framing plan, then install nails in all holes including diamond shaped holes. Full length common nails should be installed in all slant nailed hangers to insure nail penetration into the supporting member.

Application Type			Fastener
and Image	MiTek USP	Simpson	Schedule
Top Mount Single ply I-Joist to Wood Framing or Nailer	THO	ITS	11-7/8"-in and shallower I-Joists. 10d Common Nails into Header, 10dx1-1/2" into Joist.
	TFL	MIT	14-in or deeper I-Joists. 10d Common Nails into Header, 10dx1-1/2" into Joist.
	TFI	MIT	2-3/8" or wider I-Joists. 16d Common Nails into Header for TFL, 10dx1-1/2" into Joist.
Top Mount Single ply 2X Joist to Wood Framing or Nailer	HL	JB	2x14 and shallower 2X Joists. 16d Common Nails into header.
Top Mount Multi-ply 2X or 3X beams to Wood Framing or Nailer	HDO	HUTF	(2,3,4 Ply) 2X lumber with 10d Common nails.
	KHW	HW	6X & 8X Timber with 10d Common Nails.
	PHXU	HWU	3-1/2" width or smaller structural composite or glulam EWP members. 10d Common Nails.
	PHXU	HWU	5-1/8" width or wider structural composite or glulam EWP members. 16d Common Nails.
Face Mount Single ply I-Joist to Wood Framing or Nailer	THF	IUS	16-in or shallower I-Joists. 10d Common Nails.
Face Mount Single ply 2X Joist to Wood Framing or Nailer	JUS	LUS	2x12 or shallower 2X lumber. 10d Common Nails
Face Mount Multi-ply 2X beams and 3X,4X,6X, and 8X and EWP lumber to Wood Framing or Nailer	HD	HU	(2,3,4 Ply) 2X lumber and 6X lumber with 16d Common nails into Header and 10d Common nails into joist.
	HD	HU	8X lumber with 16d Common nails.
	HD	HU	Structural composite or glulam EWP members. 16d Common Nails.
Top Mount 2X Joist to Nailer	SW	JB	10d x 1-1/2" Nails

Top Mount Multi-ply 2X or 3X or larger beams to Nailer	SWH	WNP	(2 Ply) 2x6 and deeper lumber with 10d x 1-1/2" Nails
	SWH	W	4x6-in or shallower lumber with 10d x 1-1/2" Nails
	ВРН	ВА	4x8-in or deeper lumber with 10d x 1-1/2" Nails
	KHW	HW	4X, 6X, 8X Lumber attached to 3X mimimum letter. 16d x 2-1/2" Nails to nailer. 10d Common to joist.
	PHXU	HWU	Structural composite or glulam EWP members. 16d Common Nails to nailer. 10d x 1-1/2" to Joist. 4X Minimum Nailer.
Top Mount Single ply I-Joist to structural steel			
	THO	ITS	11-7/8"-in and shallower I-Joists. #10 Self Tapping screws into beam, 10dx1-1/2" into Joist.
	TFL	MIT	14-in or deeper I-Joists. #10 Self Tapping screws into beam, 10dx1-1/2" into Joist.
Top Mount Single ply 2X to Structural Steel			
	SW	LB	#10 Self Tapping Screws. 10d x 1-1/2" Nails into Joist
Top Mount Multi-ply 2X or 3X beams to Structural Steel	HDO	В	3X and 4X Lumber with #10 Self Tapping Screws, 10d Common Nails into Joist
	KHW	HW	6X and 8X Lumber with #10 Self Tapping Screws. 16d Common Nails into joist.
	НВРН	НВ	3-1/2" width or smaller structural composite or glulam EWP members. #10 Self Drilling Screws or weld to Beam. 16d Common Nails into Joist.
	КННВ	ННВ	5-1/8" width or wider structural composite or glulam EWP members. #10 Self Drilling Screws or weld to Beam. 16d Common Nails into Joist.
Mudsill Anchor	FA4	MASA	10d x 1-1/2" Nails
Holdown-Embedded Strap	STAD10	STHD10	Installed directly to Framing, 10d x 1-1/2", 10d Common or 16d Sinker. Installed over sheathing
	STAD14	STHD14	with 10d Common or 16d Sinker Nails
Holdown-Nailed w/Anchor Bolt	HTT45	HTT4	Install Directly to Framing with 10d Common or 16d
	HTT45	HTT5	x 2-1/2" Pnuematic
Holdown-Screwed or Bolted w/Anchor Bolt	PHD2A	HDU2	Install Directly to Framing with Manufacturer Provided Screws. Retighten nuts before closing walls.
	PHD4A	HDU4	
	PHD5A	HDU5	
	UPHD8	HDU8	
	UPHD11	HDU11	
	HPHD14	HDU14	
	TD15	HD19	Installs with Bolts

Chrono			[
Straps	CMSTC16	CMSTC16	-
	CMST14	CMST14	1
	CMST12	CMST12	Installed directly to Francisco 40 day 4 4/08 with 40 day
0 0 0 0	RS300	CS22	Installed directly to Framing, 10d x 1-1/2" with 10d Common or 16d Sinker. Installed over sheathing
	RS250	CS20	with 10d Common or 16d Sinker Nails
/	RS200	CS18	
	RS150	CS16	
	RS14-100	CS14	
Framing Clips	MPA1	A35	Installed directly to Framing, 8d x 1-1/2" with 8d Common or 16d Sinker. Installed over sheathing with 8d Common or 16d Sinker Nails
	MP4F	LTP4	
Hurricane Ties	RT15	H1	Installed directly to Framing, 8d x 1-1/2" with 8d Common or 16d Sinker. Installed over sheathing with 8d Common or 16d Sinker Nails
Post Caps	РСМ	PC	
	EPCM	EPC	Installed with 16d Common or 16d x 2-1/2" Nails.
	С	ВС	
Post Bases	WE	РВ	Installed with 40d Company and 6d to 0.4/0" Note:
	WAS	PBS	Installed with 16d Common or 16d x 2-1/2" Nails.