

Replacement Parts for *MiTek*[®] Roof Truss Tables

Mechanical Part Category	MiTek Part #	Part Description	Keep in Stock
Table	31559-501	Anchor plate kit (1 per table)	no
Table	563081	Scale for scale bed (optional)	no
Table	349102	Hardware for scale bed (3 for each scale bed)	no

Pneumatic Part Category	MiTek Part #	Part Description	Keep in Stock
—	See Drawing 31340-501	Entire air kit	no
Ball Valve Assembly	See Drawing 84873-501	Ball valve	no
Ball Valve Assembly	See Drawing 84873-501	Tees, connectors, and hoses	1
Cylinder Assembly— Receivers	See Drawing 84871	Cylinder, connectors, and hoses	1
Cylinder Assembly— Tables	See Drawing 84870	Cylinder, connectors, and hoses	1
Main Pressure Source	See Drawing 31340-601	Air regulator, hose, and connectors	no
Filter/Regulator	438559	Replacement filter/regulator	no
Filter/Regulator	438575	Filter element for regulator	1
Filter/Regulator	438579	Service kit for filter/regulator	no
High Slope Bumper	31337	Replacement bumper for high slope ejectors	1
Setup Assembly Kit	63840-505-1	Air kits for 5-table setup	no
Setup Assembly Kit	31345-501	Entire installation kit, JHFM-84868-501	no
Setup Valve Assembly	434587	Seal kit for inline valve	no
Setup Valve Assembly	See Drawing 31345-501	Setup valve	no
Setup Valve Assembly	434429	Foot valve	no
Setup Valve Assembly	434358	Repair kit for pilot valve (includes seals, valve inserts, and springs)	no
Setup Valve Assembly	See Drawing 31345-501	Tees, connectors, and hoses	1
Setup Valve Assembly	See Drawing 84870	Cylinder, connectors, and hoses	no