BUGLE HEAD

MiTek®

EXTERIOR STRUCTURAL WOOD SCREW

FOR GENERAL PURPOSE AND WOOD-TO-WOOD CONNECTIONS



LOAD TABLE

			Dimensions (in)				DF/SP		SPF		LVL	
							Allowable Loads (Lbs.) ⁴ Wood to Wood		Allowable Loads (Lbs.) ⁴ Wood to Wood		Allowable Loads (Lbs.) ⁴ Wood to Wood	
	USP	Ref.					Shear ²	Withdrawal ³	Shear ²	Withdrawal ³	Shear ²	Withdrawal ³
Size (in)	Stock No.	No.	L	SH	T	Finish ¹	100%	100%	100%	100%	100%	100%
1/4 x 2-1/2	WSBH25-EXT		2-1/2	1/4	2	EXT	179	199	151	141		
1/4 x 4	WSBH4-EXT		4	1-3/4	2	EXT	212	282	179	208	252	339
1/4 x 6	WSBH6-EXT		6	3-3/4	2	EXT	328	282	288	208	283	339
1/4 x 8	WSBH8-EXT		8	5-3/4	2	EXT	328	282	288	208	283	339
1/4 x 10	WSBH10-EXT		10	7-3/4	2	EXT	328	282	288	208	283	339

¹⁾ EXT = Exterior Coat.



PACKAGING TABLE

			Retail Box (Offering	50-count P	ack	Mini Bulk Offering		
Finish	Use	Size (in)	USP Stock No.	Box/Ctn Qty	USP Stock No.	Box/Ctn Qty	USP Stock No.	Box/Ctn Qty	
	Exterior	1/4 x 2-1/2	WSBH25-EXTR25	10-pack/25-ea	WSBH25-EXTR50	5-box/50-ea	WSBH25-EXTMB	2-box/200-ea	
Exterior	for General	1/4 x 4	WSBH4-EXTR12	10-pack/12-ea	WSBH4-EXTR50	5-box/50-ea	WSBH4-EXTMB	200-ea	
Coat	Purpose wood-	1/4 x 6	WSBH6-EXTR12	10-pack/12-ea	WSBH6-EXTR50	5-box/50-ea	WSBH6-EXTMB	200-ea	
(EXT)	to-wood	1/4 x 8	WSBH8-EXTR12	10-pack/12-ea	WSBH8-EXTR50	5-box/50-ea	WSBH8-EXTMB	200-еа	
	connections	1/4 x 10	WSBH10-EXTR12	10-pack/12-ea	WSBH10-EXTR50	5-box/50-ea	WSBH10-EXTMB	200-еа	

CUSTOMER SERVICE: 1-800-328-5934 | MiTek-US.com

²⁾ Shear and withdrawal load for wood-to-wood connections assume a side member thickness of 1-1/2-in for DF/SP and SPF allowable loads and 1-3/4-in for LVL allowable loads.

³⁾ Withdrawal loads are derived from the minimum of head pull through tests and withdrawal capacity of threaded portion in main member.

⁴⁾ Load are for 100% duration of load, and may be increased for the other duration factors in accordance the NDS.